## **BUCKINGHAM TOWNSHIP**

P.O. Box 413, Buckingham, Pennsylvania 18912 Phone (215) 794-8834 • Fax (215) 794-8837 Website - www.buckinghampa.org



## **Requirements for Tank Installation / Removal**

- Complete general application including applicant's signature and property owner's signature.
- Prepare plot plan showing location of storage tank to be removed.
- The Township Fire Marshal must be notified of the date the tank removal is to begin. Notification should be made no later than 48 hours prior to start date.
- An inspector must be onsite when the tank is removed from the ground. Site inspections will be conducted during the removal.
- Provide proof of Workers Compensation with Buckingham Township as certificate holder or complete our Workers Compensation exemption form, notary required. Permits will not be issued without this paperwork.